

**GEN 2.5 LIST OF RADIO NAVIGATION AIDS**

<b>ID</b>	<b>Station</b>	<b>Facility</b>	<b>Purpose</b>
<b>FF</b>	Flic-en-Flac	NDB	E
<b>IPL</b>	Plaisance	DME	A
<b>IPL</b>	Plaisance	LLZ	A
<b>IPL</b>	Plaisance	GP	A
<b>MS</b>	Plaisance	NDB	AE
<b>PLS</b>	Plaisance	DVOR/DME	AE
<b>RS</b>	Plaine Corail	NDB	AE
<b>AGG</b>	Agalega	NDB	AE
	Blue Bay	FM	A
	Bigara	ZM	A

Note : Purpose ( A = Aerodrome, E= Enroute ) is meant for the qualifier line of a NOTAM.